


SPRT®

SP-EU802 PRINTING UNIT USER'S MANUAL

(SP-EU802)



(Ver 1.05)

Beijing Spirit Technology Development Co., Ltd

www.spert-printer.com

Safety Instruction

Safety warning

- 1) The print head is heating parts, do not touch the print head and surrounding parts during printing and end printing.
- 2) Do not touch the surface of the print head and connection socket, avoiding to damage the print head because of the electrostatic.

Notice

- 1) Printing units should be installed in a flat, stable place;
- 2) Keeping enough space around the printing units to be convenient for operation and maintenance;
- 3) Far away from water for all printing units;
- 4) Do not use and store printing units in high temperature, damp and polluted places. Avoid sunlight, strong light and heat direct sources;
- 5) Avoid the printing units in the vibration;
- 6) Avoid the damp air condensation on the surface of the printing units. If condensation has been formed, do not open the power of the printing units before the dew disappear;
- 7) Keep the printing units power adapter connected to a properly grounded outlet; avoid using the same socket with large motor or other devices which can lead to the power supply voltage fluctuation;
- 8) If no use the printing units for a long time, please disconnect the power of the power adapter;
- 9) To avoid water or conductive material into the printing units interior, once occurred, should immediately shut off the power;
- 10) Printer shall not print under the conditions of no paper, otherwise will seriously damage the printing roller and the thermal print head;
- 11) In order to guarantee the print quality and product life, suggest to use the recommended paper and same quality paper;
- 12) In the case of printing effect meets the requirement, suggest users to set lower level print density as much as possible, to avoid affect the life of the print head;
- 13) The user shall not remove printing units for maintenance.

Contents

Brief Introduction.....	1
Chapter 1 Characteristics and performance.....	1
1.1 Print performance.....	1
1.2 Print paper.....	1
1.3 Character set.....	2
1.4 Interface.....	2
1.5 Printing control command.....	2
1.6 Power supply.....	2
1.7 Installation Dimension.....	2
1.8 Work Environment.....	3
1.9 Model Classification.....	3
Chapter 2 Operating instructions.....	4
2.1 Printing Unit components.....	4
2.2 Instructions for paper install.....	4
2.2.1 Paper Loading.....	4
2.2.2 Solution for paper jam of cutter.....	5
2.3 Interface connection.....	5
2.3.1 Serial interface connection.....	5
2.3.2 Parallel interface connection.....	6
2.3.3 Power supply connection.....	8
2.4 Lights and Buttons Operation.....	8
2.5 Normal working mode.....	9
2.6 Self-test.....	10
2.7 HEX Printing mode.....	10
2.8 The printer parameters setting.....	10
2.9 Enter into the program upgrading mode.....	11
2.10 Installation and use notes.....	11
Appendix A: Parameters setting.....	14

Brief Introduction

SP-EU802 printer is a new thermal line panel printer, with drop-in paper easy loading, auto cutter, Black label detection, printing speed faster and more reliable.

SP-EU802 printer easy operation, applications widely, especially to queue machine, POS for bank and the business of all kinds of needed docs to print.

Statement

This product belongs to class A. In the living environment, this product may cause radio interference. In that case, the user need to take practical measures to interference.

Chapter 1 Characteristics and performance

1.1 Print performance

- Printing method: direct line thermal;
- Printing paper width: 79.5±0.5mm
- Resolution: 8 dots/mm, 576 dots/line
- Printing speed: 220mm/s(thermal paper max)
- MCBF: (1) Printing head life: 100km
Operating conditions:
 - * Print font 12 × 24 ASCII, print 50 lines per time, Intermittent reprint
 - * Thermal paper(2) Auto cutter life: 1,000,000 cuts.
- Effective printing width: 72mm

1.2 Print paper

- The mode of thermal paper: TF50KS—E(Japan paper co. ltd)
AF50KS-E(JUJO THERMAL)
- Thermal paper roll: width ----- 79.5±0.5mm
thickness ----- 0.06mm~0.08mm
Paper roll inner diameter-----φ14mm
Paper type-----79.5× φ 120mm(max)

1.3 Character set

- ANK character set:
 - 12×24 dot, 1.5(width)×3.00(high)mm
 - 9×17 dot, 1.125(width)×2.125(high)mm
- Chinese:
 - 24×24 dot, 3.00(width)×3.00(high)mm
 - 16×16dot, 2.00(width)×2.00(high)mm

1.4 Interface

- RS—232C serial port:
 - DB-9 socket(pin point),support XON/XOFF and DTR/DSR.
 - Baud rate:1200,2400,4800,9600,19200,38400,57600,115200bps adjustable.
 - Data structure:One start bit + (7 or 8)data + one stop bit.
 - Verify:No validation or odd and even is optional.
- Parallel port:
 - 36pin,8 bits parallel,BUSY/ACK handshaking protocol agreement,TTL.
- USB port:
 - Standard USB port.

1.5 Printing control command

- Characters print command:support the double width and height printing of ANK characters,self-defined characters and Chinese; characters lines spacing can be adjusted.
- Bitmap print command:Support printing bitmaps with different density and downloaded graphics.
- GS bar code print command: support UPC-A,UPC-E,EAN-13,EAN-8,CODE39,ITF25,CODABAR,CODE93,CODE128,PDF417,QR Code,DATA Matrix bar code print.
- Zebra CPCL command.

1.6 Power supply

- DC24V±10%,2A,VH3.96-4P power socket

1.7 Installation Dimension

- Outline dimension: 237mm×154mm×147mm(L×W×H)
- Detail size as below Figure1-1:




Figure.1-1 SP-EU802 KIOSK printer size

1.8 Work Environment


- Working stability: 0 ~ 50°C Operating Relative Humidity: 10% ~ 80%
- Storage stability: -20 ~ 60°C Storage relative humidity: 10% ~ 90%

1.9 Model Classification

Model	Interface
SP-EU802SU	RS-232C and USB
SP-EU802P	Parallel

Chapter 2 Operating instructions

2.1 Printing Unit components




2-1 printing units components

2.2 Instructions for paper install

2.2.1 Paper Loading

Thermal paper installed as below:

In the state of power-on, pull out a little paper from the paper roll, then put the paper into the mouth of printing mechanism, the printer will auto paper feed

 **Attention**

1. Pay attention to in the direction of the paper roll, keep the print surface towards the head.
2. Please do not move the paper forward or back by hands.
3. Keep clean for the printer head or will effect the quality of the Printing

2.2.2 Solution for paper jam of cutter


If the cutter is jammed, turn off the power and turn on the printer again, the cutter will recover. If the paper is jammed, please open the rubber roll and take out the paper. If the cutter does not recover after reset, you can move the plastic gears on the cutter to recover the cutter.

If you want to keep the data when the cutter is jammed, please do not turn off the power and use the manual method to recover the cutter. Then open the rubber roll and take out the jammed paper, now turn off the rubber roll. The printer will recover from the paper cutting errors.

2.3 Interface connection

2.3.1 Serial interface connection

SP-EU802 printer serial interface is compatible with RS-232C, support DTR/DSR and XON/XOFF handshaking protocol. Its interface is DB-9 pin type socket outlet. The pin number of serial interface socket as shown in figure 2-5:



2-5 RS232 socket

Each pin signal is defined as shown in figure 2-5:


Pin No.	Signal name	Signal direction	Source	Explain
1	NC	----	----	
2	RXD	input	Host	Printer receive data from computer

3	TXD	output	printer	Printer send control code XON/XOFF and data to computer.
4	DTR	output	printer	When the signal show "MARK", it is means the printer is busy and can not receive data, when the signal show " SPACE", it is mean the printer get ready and can receive data.
5	GND	----	----	Signal ground
6	DSR	input	host	When the signal show "MARK", it is means the printer is busy and can not receive data, when the signal show " SPACE", it is mean the printer get ready and can receive data.
7	RTS	output	printer	Same as DTR
8	CTS	input	host	Same as DSR
9	NC	----	----	

Mark: ①"Source"means the original place of the signal

② Signal logic level is EIA

The baud rate and data structure have been set as 9600bps/8 data bits/no calibration and 1stop bit under connected with serial. SP-EU802 printer's serial interface can be connected to the standard of RS-232C interface, the right connect way as figure 2-6.



2-6

2.3.2 Parallel interface connection


SP-EU802 printer parallel interface is compatible with CENTRONICS, support BUSY or ACK handshaking protocol, The 36 pin number of parallel interface socket as shown in figure 2-7:

Pin No.	Signal	Signal direction	Explanation
1	STROBE	in	Gated FF, Rising along the read data
2	D1	in	These signals representing one to eight

3	D2	in	parallel data information, each signal when the logic is "1", it is high level, logic is "0" means low level.
4	D3	in	
5	D4	in	
6	D5	in	
7	D6	in	
8	D7	in	
9	D8	in	
10	ACK	out	
11	Busy	out	High level means it is busy for printer and can not receive data
12	PE	out	High level means paper end sensor
13	SEL	out	The resistance to high level
17	FG	...	Frame GND
18	Logic-H	...	Logic "1" level
32	nFault	out	low level means printer errors
14,15,17,18,34,36	NC	...	No Connect
16,19-30,33	GND	...	Ground, Logic "0" level
35	+5V	...	+5V power supply

2-7 parallel interface socket

Parallel connection interface signal sequence as shown in figure 2-8:



2-8 Parallel connection interface signal sequence

2.3.3 Power supply connection

For SP-EU802 printer, the power supply is external $24V \pm 10\%$, 2A, socket is VH3.96-4P type, Shape and pin definition as shown in figure 2-9,




Figure 2-9 power socket and pin definition

2.4 Lights and Buttons Operation

SP-EU802 printer has one button and three lights.

【FEED】 is paper feeding button, available to print commands allow or prohibit button switch function, in the condition of allow button control, press 【FEED】 button printer feeding paper, loosen 【FEED】 button, stop feeding paper.

Green power indicator light is for power light. POWER indicator lighting means printer has been switched on.

Red light for PAPER OUT indicator is paper status indicator. When it is light, it means the printer is out of paper.

Red light for the ERROR is Error status indicator, When the print working with normally, the red Error light is off, the light is flashing as abnormal alarm status, if the indicator is long on, means the printing mechanism is opened in the process of printing.

Error light flash: means there are something wrong with printer.

According to blink in a different way, indicate the different types of printer error:

1, Non-recoverable error, The times of lights flashing said wrong type, then will light for a long time.


2, Recoverable errors, the times of lights flashing means the error type, then will light-off for a period.








3, Automatic recovery error, the lights will flash continuous.

4, Paper out, lack of light long on paper. When printing on the rubber roller no longer test for a lack of printer paper, only check whether have paper.


Show as below:

a. Non-recoverable error, the lights will flash for many times later will lighting for a period, then circulation, the times of the lights flashing show the errors type.


Error type	Error description	ERROR lights flash type
Non-recoverable error	LED flash once:Memory read error	

	LED flash two times:Overvoltage	
	LED flash three times:Under voltage	
	LED flash four times:The CPU execution error (error address)	
	LED flash five times: UIB error	
	LED flash six times: FLASH write error	
	LED flash seven times:Write error parameter	
	LED eight times:Temperature detection circuit error	

b. Recoverable errors, the lights will flash continuous, then light-off for a period.

Error type	Error description	ERROR lights flash type
Recoverable errors	LED flash once :cutter position error	

c. Automatic recovery error, the lights will flash continuous. Including the print head temperature error and the upper cover to open the print process error.

Error type	ERROR lights flash type	ERROR lights flash type
Recoverable errors	LED flash continuous: the printer head is overheating, or open the wrong printing mechanism in the process of printing roller.	

2.5 Normal working mode

When printer is off, 【printing rubber roller】 is closed, then open the power button, Status indicators and paper out indicator shine alternately twice and then off, printer enter into the normal working mode.

2.6 Self-test

Self-test can detect the printer is working correctly or not, if it can print out self-test receipt correctly, it is mean everything is normal except the port connection with PCB board, or will be need repaired.

Self-test print out in sequence: name of manufacture,printer mode,software version,interface type,parameter default value of printer's,96 characters in the ASCII code,default code page content(set the language as English)or Chinese character name(if language set as Chinese),bar code type.

The self-test method is press the button of **【FEED】** to open the power supply, then the printer will print out the self-test receipt.

2.7 HEX Printing mode

According to below steps, make the printer enter into the HEX printing mode.

- 1, Open the rubber roller of printing agencies;
- 2, Press the button of **【FEED】** to open the power supply;
- 3,Close the rubber roller printing agencies, then print out the three lines content as below:

Hexadecimal Dump

To terminate hexadecimal dump,

Press FEED button three times.

It means the printer has entered into HEX printing mode, under this mode, all the input content will be printed out as HEX DUMP, the paper will online after press the **【FEED】** button once, totally three times, print out "**** Completed ****", quit HEX DUMP mode.

2.8 The printer parameters setting

This function is to set up some simple parameters for the printer.

Enter into parameter setting method:

In shutdown mode, open the **【printing rubber roller】** first, press the button of **【FEED】**, then open the power supply, after the status indicators and lack of paper lights flashing alternant release the button of **【FEED】**. Press the button of **【FEED】** twice again, then close the **【printing rubber roller】**. The printer enter into parameter setting mode. And print out the first item of parameters and its current value which can be setted. The details for setting method reference appendix A.

The method to quit the parameter setting

Open the **【printing rubber roller】** first, press the button of **【FEED】**, then close the **【printing rubber roller】** and release the button of **【FEED】**, save the setting values of the parameters and exit. Enter into the normal working mode.

If the printer's power supply is closed directly, the setting parameters will lose.

2.9 Enter into the program upgrading mode


When printer is off, open the 【printing rubber roller】 first, press the button of 【FEED】, then open the power supply, after the status indicators and lack of paper lights flashing alternant release the button of 【FEED. Press the button of 【FEED】 five times, then close the 【printing rubber roller】 . The printer enter into the program upgrade mode. Then the status indicator light will flash as 1s speed.

Quickly access method: In printer off mode, open the 【printing rubber roller】 first, press the button of 【FEED】 , then open the power supply, then release the button of 【FEED】 quickly. The printer enter into the program upgrade mode. Then the status indicator light will flash as 1s speed.

Attention: After entering into the program upgrade mode. If the paper out indicator lights, it means the program of this interface can not be upgraded. Serial port,parallel and USB port support upgrade online.


2.10 Installation and use notes

1.The connection between the paper exit and the paper exit position of the device suggested to be one of the following figures.




2. When the paper exit port and Cabinet outlet are connected in the above figure, in the structure of Figure 1 and Figure 2, there should be a gap between the paper exit of the printer and the paper exit of the device. See the figure below.

There is a certain gap between the paper exit and the equipment
(recommended one side 1-3mm, as shown in Figure A)



3. The printer must be firmly installed to prevent the printer from shifting due to external force and causing paper blockage. If installed on the sliding rail, it is necessary to make the sliding rail limit mechanism.

4. If the paper bin and support need to be designed separately, the paper bin (paper rack) and movement are prohibited to be placed in the center continuously. The width of the paper bin (paper rack) is paper width +1mm. If the diameter of the paper roll installed is greater than 80mm, buffer mechanism should be added, the common buffer mechanism is shown in the figure below



5. In the process of use, it is necessary to wait for the printer to finish cutting paper before tearing/taking paper, so as to avoid paper blocking and deviation caused by paper tearing.




6. In the process of use, do not cover the paper nozzle with your hands, and make sure there is no foreign body covering before the paper nozzle to avoid paper jam.

7. Ensure the paper head is flat and free from debris when loading the paper, so as to avoid slanting the paper or getting stuck in the machine head.

8. the printer is not suitable for working in the vibration environment, if you use the vibration environment, you must add damping design.

9. Printer in dust, oil, moisture, high temperature and other harsh environments, must do effective protection measures, so as not to affect the normal use of the printer.

10. After the printer cots are opened for maintenance, check whether they are closed in place when they are closed, and ensure that the card buckle is completely locked, as shown in the figure below




Appendix A: Parameters setting


This appendix shows the way, through which printer's parameters are sett through the button.

Setup instruction: use the button of 【printing rubber roller】 to choose the setting items, change the item by press the button 【printing rubber roller】 , and print out the current value. Use the button of 【FEED】to set the parameter, the parameter will be changed by press the 【FEED】 button.


Full setting:




Baud rate:




Language:




Font dots:




Print density:



Print speed:



Re-printing lack of paper:



Black label mode:

